




**THE ORIGINAL  
BIGBLU<sup>®</sup>**

**MICROLEAK  
DETECTOR**

**Ultra-Sensitive Formula**

**Long Lasting Bubbles**



32oz (946ml)

## BENEFITS

Big Blu is the original micro leak detector known for its long lasting bubbles. This one of a kind elastic liquid easily clings to all surfaces. It is the only bubble leak detector capable of identifying leaks down to 0.65oz/yr. It is safe to use all gases including oxygen. Freeze protected to 32°F, non-corrosive, biodegradable, and NSF approved for use around food. Please see directions and visit our website for more information.



Manufactured by:



a Family Company Since 1987.

## DIRECTIONS



Turn off or Disconnect all power from system.



Coat all surfaces with a flat liquid free of foam.



**Tip:** Focus on threaded connections, joints, and valves. Read our "Leak Detection Manual" online for more information.

Bubbles will form instantly for most leaks. Wait 5-30 minutes. Micro leaks will develop and appear as white foam cocoons or tiny bubble clusters. Place unit back into operation and check for vibration leaks.



Wipe or rinse off surfaces if water is available.



All done!

## OUR STORY

**Designed  
by a service tech  
for a service tech**

"As a service technician for over 17 years, I combined my HVAC/R expertise with my chemistry background to develop a family of products that every technician will want on their truck.

Refrigeration Technologies is the most trusted name for innovative products in the industry."

**Thank you for purchasing!**

John Pastorello  
Founder & CEO



Part# RT100S



## Big Blu

**SIGNAL WORD:** None Required  
**PICTOGRAM:** None Required

**HAZARD STATEMENT:**  
This product is not classified as hazardous according to GHS.

**PRECAUTIONARY STATEMENTS:**  
Avoid all unnecessary exposure by wearing gloves, goggles and use in well ventilated areas.  
**KEEP OUT OF REACH OF CHILDREN**

**FIRST AID: Inhalation:**  
Assure fresh air breathing. Allow the victim to rest.

**Skin contact:**  
Remove affected clothing and wash all exposed skin area with mild soap and water.

**Eye contact:**  
Rinse immediately with plenty of water. Obtain medical attention if pain, blinking or redness persist.

**Ingestion:**  
Rinse mouth. Do NOT induce vomiting. Obtain emergency medical attention.

**DISPOSAL:**  
Dispose of in accordance with your local regulations. Recycle Container.

**Manufactured by:**  
Refrigeration Technologies,  
1111 N. Armando St, Anaheim, CA, 92806 USA.  
Ph: 714-238-9207.  
Fax: 714-238-9234. Web: www.refrig.com  
24 Hour Emergency Phone Chem-Tel: 1-800-255-3924.  
International Calls 1-813-248-0585

**See the S.D.S. for more information**

**Distributed in Australia and New Zealand by:**  
Supercool Asia Pacific Pty Ltd,  
ABN: 71 011 044 385,  
14 Motorway Circuit, Ormeau,  
QLD, 4208, Australia

Ph: (07) 5549 4000. Fax: (07) 5549 4004.  
www.supercool.com.au  
Emergency Ph: (07) 5549 4000

[www.refrig.com](http://www.refrig.com)